

How to Read an AMI Meter (Advance Metering Infrastructure)

Opening and closing the plastic cover of an AMI meter resets the reading between two options: cumulative Cubic Feet (CF) or Gallons Per Minute (GAL).



Cubic Feet (CF)

Reading is 0.411 Cubic Feet (CF)



Gallons Per Minute (GAL)

True Decimal Reading is 0.000 Gallons

MMWD water bill is in CCF (Hundred Cubic Feet)

The first 4 digits from the left are CCF

This reading is 5.82 CCF

